


# Comfort 350 Top

## Dimensional drawing (Right version)



### Connections:

1. Outdoor air
2. Supply air
3. Extract air
4. Discharge air
5. Condensate drain